
Item No.: ET225E

Installation guide




Accessory list

Attention: The drawings below are for guidance only and they may differ slightly from the product and fittings received. Please contact our customer service department if you have any queries.


No.	Image	Spec	Qty
A	0	MG	4
В	0	MB	8
C	0	MB	8
D	⊕	SH4.2	6
E	6	Cable tie	8
F	90	St4.2	8
G		Allen Key 4x4mm	


Component list

No.	Part	Qty	No.	Part	Qty
1	Feet	2	2	Lifting Column	2
No.	Part	Qty	No.	Part	Qty
3	Connection rod	2	4	Left Supporting Beam	2
No.	Part	Qty	No.	Part	Qty
(5)	Right Supporting Beam	2	6	Side bracket	2
No.	Part	Qty	No.	Part	Qty
7	Adapter arm	1	8	Adapter	1
No.	Part	Qty	No.	Part	Qty
9	Control Box	1	10	Handset (Option)	1
No.	Part	Qty	No.	Part	Qty
11	Adapter cable	1	12	Power Plug	1










Common fault treatment

ras following this will help you detected and eliminate the common fault and eliminate. If the fault you may is not listed below, please contact with your supplies, citally themanulacturer and professionals are capable for investigating also correcting those fault and error.

Fault phenomenon	Method		
Aprile supply the toning fleshilk	1. Check It all the cables to connected well		
	8. Contact your supplies or dealer		
No response white pressing up arrow stopps given after	1 Chook It all the eables be connected well		
connected with a flower aupply	& Contact your supplier or dealer		
Malantana basa hasar	1 Check if evertoaded, max loading: 100kg:		
Rising in a low speed	è Centari your aupplier er dealer		
The motor not move as instructed	1. Contact your supplier or dealer		
do dawn but not go up	1 Reposition		
no noun entirection for ab	8. Contact your aupplier or dealer		
Downward sliding	1 Check if evertoaded, max leading: 100kg:		
command andmin	& Contact your supplier or dealer		
Eranuanth Banastton	1. Check if exertoaded, max loading: 100kg:		
Frequently Reposition	8 Contact your aumplier or dealer		
Overwork	1. Restart after syspend for 18mins while		
Only cred that some on them of FS	& Contact your supplier or dealer:		
Not enough up Adown height	Press 'M' and '3' together for 3 seconds or more, after hearing conflithnous beaping for twice will teacher factors satitude. Contact your supplier or dealer.		



Power supply: AC100V-240V,50/60Hz

Service Environment: 0:40°C

Unplug the power plug before cleaning, wipe the dust on surface with slight wet disheloth when cleaning, be careful not to let the drops into the internal parts, not loose

1. The electric box contains electronic components, metals, plastics, wires etc., so dispose of it in accordance with each country's environmental legislation, not the

general household waste.

 B. Check carefully to ensure correct and complete assembly before using.
 Be familiar with all functions and program settings of the product before first use.
 Children are forbidden to play on the product because of unforeseen action when playing, so any dangerous consequences caused by this improper action will not be on manufacturers.

8. Slight noise caused by the V-ribbed belt or brake system due to structure will not have any effect on the use of the equipment.

9. Corrosive or abrasive materials are forbidden to clean the equipment. Must ensure that the cleaner used will see that the controlled.

that the cleaner used will not pollute the environment.

10. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. with the appliance.

with the appliance.

11. Cleaning and user maintenance shall not be made by children without supervision.

12. If the supply cord is damaged, it must be replaced by the manufacturer, its services agent or a similarly qualified person in order to avoid a hazard.

13. Please make sure there is no hazard sources in your operating environment. e.g., do not litter the tools around. Always be careful to treat the packaging materials in order to avoid any possible danger, e.g. plastic bag may lead to choking hazard to children.

14. Keep the original package of the equipment if necessary in case of the future use in transportation. transportation

Waste disposal





This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling

